

Electronics for Positive Displacement Flow Meter

S2000 Series

1. Pulse output




Specifications	
Power supply	10...30VDC
No load current	<9mA
Output	Push-Pull (PNP / NPN)
Reverse polarity protection	Yes
Short circuit protection	Yes
Probe operating temperature	-40...212°F (Optional -40...302°F / -40...446°F) -40...100°C (Optional -40...150°C / -40...230°C)
Ambient temperature	-40...185°F (-40...85°C)
Electrical connection	M12 x 1 plug
Protection class	M12 x 1 plug: IP67

Wiring

M12 plug				PNP	NPN
	Pin	Color	Signal		
	1	Brown	Power +		
	4	Black	Pulse		
	3	Blue	Power -		

Dimensions in mm



2. Linearized pulse output



Specifications	
Power supply	12...30VDC
No load current	<20mA
Output	Push-Pull (PNP / NPN)
Reverse polarity protection	Yes
Short circuit protection	Yes
Probe operating temperature	-40...212°F (Optional -40...302°F / -40...446°F) -40...100°C (Optional -40...150°C / -40...230°C)
Ambient temperature	-40...185°F (-40...85°C)
Electrical connection	M12 x 1 plug
Protection class	M12 x 1 plug: IP67

Wiring

M12 plug				PNP	NPN
	Pin	Color	Signal		
	1	Brown	Power +		
	4	Black	Pulse		
	3	Blue	Power -		

Dimensions in mm





4. Intelligent transmitter with digital display




Specifications	
Power supply	10...30VDC
No load current	<12mA
Switching output	Push-pull (compatible to PNP / NPN)
	Switching capacity: 500mA (24VDC)
Analog output	2-wire 4...20mA
	Load RA(Ω) ≤ (Us-10)V/0.02A
	Linearity: <=0.01% of reading
Accuracy	<=0.02% of reading
Ambient temperature	-40...185°F (-40...85°C)
Probe operating temperature	-40...212°F (Optional -40...302°F / -40...446°F)
	-40...100°C (Optional -40...150°C / -40...230°C)
Display	4-digit LED
Material	Stainless steel 304
Electrical connection	M12 x 1 plug
Protection class	IP67

Wiring

M12 plug	Analog + 2 x PNP	Analog + 2 x NPN																		
<table><tr><th>Pin</th><th>Color</th><th>Signal</th></tr><tr><td>1</td><td>Brown</td><td>Power +</td></tr><tr><td>3</td><td>Blue</td><td>Power -</td></tr><tr><td>4</td><td>Black</td><td>Switching S1</td></tr><tr><td>2</td><td>White</td><td>Switching S2</td></tr><tr><td>5</td><td>Gray</td><td>Analog</td></tr></table>	Pin	Color	Signal	1	Brown	Power +	3	Blue	Power -	4	Black	Switching S1	2	White	Switching S2	5	Gray	Analog		
Pin	Color	Signal																		
1	Brown	Power +																		
3	Blue	Power -																		
4	Black	Switching S1																		
2	White	Switching S2																		
5	Gray	Analog																		

Dimensions in mm




5. Ex-proof intelligent transmitter




Specifications

Power supply	10...30VDC / 95...240VAC, Max. 2.2W
No load current	<12mA
Analog output	2-wire 4...20mA
Pulse output	Switching capacity: 500mA (24VDC)
Switching output	Push-pull (compatible to PNP / NPN)
Display	5-bit for instantaneous flow rate
	13-bit for total flow rate
	Volume unit: m ³ / L / gal / FT ³
	Time unit: day, hr, min, sec
	Refresh: 1s
Accuracy	0.01%
Probe operating temperature	-40...212°F (Optional -40...302°F / -40...446°F)
	-40...100°C (Optional -40...150°C / -40...230°C)
Ambient temperature	-40...140°F (-40...60°C)
Ex-proof	EX d IIC T6
Material	Stainless steel 304
Electrical connection	M20 x 1 plug
Protection class	IP65

Wiring



Dimensions in inch (mm)



Order code**1. Model**

S2000- Sensor for or positive displacement flow meter

2. Output

P1 Pulse output
P2 Linearized pulse output
A 4...20mA
D Digital transmitter
E Ex-proof transmitter

3. Temperature

T1 -40...212°F (-40...100°C)
T2 -40...302°F (-40...150°C)
T3 -40...446°F (-40...230°C)